

honestech
Easy Video Editor 3.0

User Guide



End User License Agreement

IMPORTANT : READ THE FOLLOWING TERMS AND CONDITIONS CAREFULLY BEFORE CONTINUING THIS INSTALLATION.

IF YOU DO **NOT** AGREE WITH THESE TERMS AND CONDITIONS, PROMPTLY REMOVE THE SOFTWARE FROM YOUR COMPUTER AND RETURN THE SOFTWARE, INCLUDING THE DOCUMENTATION, TO YOUR **SUPPLIER** AND YOUR MONEY WILL BE REFUNDED. IF YOU DOWNLOADED THIS SOFTWARE, PLEASE REMOVE THE SOFTWARE FROM YOUR COMPUTER AND CONTACT YOUR SUPPLIER TO REQUEST A REFUND.

In this license agreement (the "License Agreement"), you (either **individual** or an entity), the purchaser of the license rights granted by this License Agreement, are referred to as "licensee" or "You". **Honest Technology** is referred to as the "Licensor". The current version of the accompanying software ("Software") and documentation ("Documentation") are collectively referred to as the "Licensed Product". Licensor may furnish hardware with the Licensed Product ("Hardware")

1. License

In accordance with the terms and conditions of this License Agreement, the Software is the property of the Licensor and is protected by Copyright Law. While the Licensor continues to own the Software, the Licensor grants the Licensee, after Licensee's acceptance of this License Agreement, the Limited, non-exclusive license to use on copy of the current version of Licensed Product as described below. The Software is "used" on a computer when it is loaded into the temporary memory (i.e., RAM) or installed into the permanent memory (e.g., hard disk, CD-ROM, or other storage device) of that computer, except that a copy installed on a network server for the sole purpose of distribution to another computer is not considered "in use". Except as may be modified by a license addendum which accompanies this License Agreement, the Licensee's rights and obligations with respect to the use of this Software are as follows:

You May,

- I. Use the Software for commercial or business purposes in the manner described in the Documentation.
- II. Use the Software to share Internet connection, transfer data, files and images among the computer in the manner described in the Documentation.

You May Not,

- I. Copy the documentation that accompanies Software.
- II. Sublicense or lease any portion of the Software.
- III. Make illegal duplication of the software.

- 2. Copyright and Trade Secrets.** All rights in and to the Licensed Product including, but not limited to, copyrights and trade secrets rights, belong to Licensor, and Licensor holds title to each copy of the Software. The licensed Product is protected by United States Copyright Laws and international treaty Provisions.
- 3. Term.** This License Agreement is effective until terminated. Licensee may terminate this License Agreement if Licensee breaches any of the terms and conditions herein. Upon termination of this License Agreement for any reason, Licensee shall return to Licensor or otherwise destroy the Licensed Product and all copies of the Licensed Product. Upon request of Licensor, Licensee agrees to certify in writing that all copies of the Software have been destroyed or returned to Licensor. All provisions of this Agreement relating to disclaimers of warranties, limitation of liability, remedies, or damages, and Licensor's proprietary rights shall survive termination.
- 4. Executable Code.** The Software is delivered in executable code only. Licensee shall not reverse engineer, compile or otherwise disassemble the Software.

5. Limited Warranty

- a. Licensor does not warrant that the functions contained in the Licensed Product and Hardware will meet Licensee's requirements or that the operation of the Software and Hardware will be uninterrupted or error-free. Licensor does warrant that the media on which the Software is furnished and the hardware will be free from defects in materials and workmanship under normal use for a period of thirty (30) days from the date of delivery ("Warranty Period"). This Limited Warranty is void of failure of the media on which the Software is furnished has resulted from accident, abuse, or misapplications.
- b. EXCEPT AS PROVIDED ABOVE, THE LICENSED PRODUCT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LICENSED PRODUCT AND HARDWARE IS WITH LICENSE.

6. Limitation of Liability

- a. Licensor's sole obligation or liability and licensee's exclusive remedy under this agreement shall be the replacement of the defective media on which the software is furnished and/or the hardware according to the limited warranty above.
- b. In no event will licensor be liable for any consequential, incidental or indirect damages including, without limitation, any loss of data or information, loss of profits, loss savings, business interruption or other pecuniary loss, arising out of use of or liability to use the software or documentation or any hardware, even if licensor has been advised of the possibility of such damages, or for any claim by any third party.

7. General

- a. Any Software and Hardware provided to Licensee by Licensor shall not be exported or re-exported in violation of any export provisions of the United States or any other applicable jurisdiction. Any attempt to sublicense, assign or transfer any of the rights, duties or obligations hereunder is void. This Agreement shall be governed by and interpreted under the laws of the State of New Jersey, United States of America, without regard to its conflicts of law provisions. Licensor and Licensee agree that the U.N. Convention on Contracts for the International Sales of Goods shall not apply to this License Agreement.
- b. This License Agreement may only be modified or amended by a written license addendum that accompanies this License Agreement or by written document that has been signed by both you and Licensor. Site licenses and other types of enterprise licenses are available upon request. Please contact Licensor or your supplier for further information.
- c. Any controversy or claim arising out of or relating to this Agreement, or the breach of this Agreement, shall be settled by arbitration administered by the American Arbitration Association in accordance with its Commercial Arbitration Rules and Judgment upon the award rendered by the arbitrator may be entered in any court having jurisdiction thereof. The arbitration shall be held in New Jersey, United States of America.

If you have any other questions concerning this License Agreement, or if you desire to contact Licensor for any reason, please contact Honest Technology.

Table of Contents

END USER LICENSE AGREEMENT	2
TABLE OF CONTENTS	4
1. INTRODUCTION	5
1.1. WHAT IS HONESTECH EASY VIDEO EDITOR 3.0?	5
1.2. MINIMUM SYSTEM REQUIREMENTS.....	5
2. HONESTECH EASY VIDEO EDITOR INSTALLATION.....	6
3. USING HONESTECH EASY VIDEO EDITOR 3.0.....	11
3.1. IMPORT OR CAPTURE VIDEO.....	11
3.2. SPLIT AND ARRANGE CLIPS.....	19
3.3 ADD EFFECTS.....	21
3.4. PUBLISH	22
3.4.1. Publish to Disc:.....	22
3.4.2. Publish to Video File:	29
3.4.3 Upload to YouTube	31
3.4.4 Convert Video for iPod/PSP.....	32
4. UNINSTALL HONESTECH EASY VIDEO EDITOR 3.0	33

1. INTRODUCTION

1.1. What is honestech Easy Video Editor 3.0?

honestech Easy Video Editor is a video editing application that allows even novice users to edit video. The intuitive user interface makes cutting and merging clips possible with only a few clicks. You can also add intro/ending credit and add various transition and special effects using the templates.

- 24 transition effects
- 20 Special Effects
- 24 Title effects

1.2. Minimum System Requirements

Processor: Intel Pentium IV 1GHz or equivalent

Operating System: Windows XP SP2/3, Windows Vista

Memory: 256MB of RAM

Direct-X: 9.0

CD Burner: for VCD/SVCD

DVD Burner: for DVD

Others:

Direct-X 9.0

Windows Medial Format SDK 9

Windows Media Player 7


6. honestech

2. honestech Easy Video Editor Installation


2.1. Insert the installation CD in the CD-ROM drive.

2.2. Setup process will automatically start. If the installation does not start automatically, please double-click on **Setup.exe** file on the installation CD.


2.3. Installation process will start with the following screen.




2.4. Following welcome screen will appear. Click **[Next >]** to continue.



2.5. The End-User License Agreement will appear as shown below, if you accept, click **[Yes]** to continue.




2.6. Use the default destination folder or change it by clicking on **[Browse...]** button. Then click **[Next]** to continue.




8. honestech


2.7. **Select Program Folder** screen will be displayed next. Accept the default folder or choose your program folder and click **[Next >]** to continue.




2.8. Setup status screen will appear as shown below. This step is done automatically.



2.9. Installing Adobe Reader. This is optional if you already have Adobe Reader installed on your PC.




2.10. Allow the installation of Adobe Reader by clicking on **[Run]**.



10. honestech

2.11. *honestech* Easy Video Editor Setup is now complete; click **[Finish]** to complete the installation.



3. Using honestech Easy Video Editor 3.0

You can start *honestech Easy Video Editor 3.0* by simply double-clicking on this icon



Or you can start the program through the **Start** menu button by clicking

Start → All Programs → honestech Easy Video Editor 3.0 → honestech Easy Video Editor 3.0

3.1. Import or Capture Video

In this section, you will capture your video.



Select and click on the video input source that you would like to use.



Import File: Click to import from an existing video file.



Import from DV Cam: Click to import from a DV-camcorder.



Import from HDV Cam: Click to import from an HDV camcorder.



Import from webcam: Click to record video using a webcam or record video from a non-hardware encoding capture device.



Capture Window:



Video Playback Controls: Click to play, pause, stop, rewind, or fast forward the video. These options are not available when capturing from an analog device.



Record: Click to start recording.




Stop: Click to stop recording. The recorded video will be saved in your output folder.



Recording Time: Enter a value (hours: minutes: seconds) to set the duration of the recording. The recording will stop automatically after the duration has elapsed. This is very useful if you know the length of the movie you are recording. It is recommended that you always set a recording time to prevent unnecessary or unwanted recordings from consuming valuable recording space on your computer's hard drive. You can always stop the recording manually before the recording time has fully elapsed.



Recording Status: This panel displays the selected recording format, recording time elapsed, and file size of the current recording.




Aspect Ratio: Set the aspect ratio for your recorded video.




Exit: Click to exit the capture window and return to the editing screen.



Options: Click to select your video input device (e.g. webcam or DV camcorder), choose your recording format and change the recording quality (affects record time).



Selecting Video Capture Device:



Using the drop-down menu shown above, you can select the video input device. Easy Video Editor 3.0 will detect and list all available video input devices (select **USB2.0 VIDBOX** if you are using the **VIDBOX**).


Note: Importing video and audio is only possible with a “non-hardware encoding” capture device.



Video Device Settings: Select the type of video input cable you have connected to your video device.




Selecting Audio Capture Device:



Select the audio device that you want to use (select **USB VIDBOX Audio** or **USB Audio Device** if you are using the **VIDBOX**).



Audio Device Settings: Configure the settings of the selected audio device and adjust the volume (if allowed).



Video Recording Format:

Format :

Select the video file format from the drop down menu (VCD / SVCD / DVD / Long DVD / AVI / WMV).


Video Format Settings: Configure additional settings based on

the selected video format.

- DVD, Long DVD

You can select from three Resolution Settings: (352*240(288) / 352*480(576) / 720*480(576)). Long DVD format will allow you to record longer video to your writable DVD than the normal DVD format, but video quality will be slightly lower.

Note: Selecting a resolution higher than the recommended setting may cause dropped frames, resulting in poor video quality.



- WMV

Enter Header Information for WMV files.

Selecting Video Type:

Select the video standard format you wish to record your video in (e.g. NTSC / PAL; * Select NTSC for North America).

Selecting Video Quality:

Adjust the quality for the recorded file (Best / Good / Normal / Average). The higher the quality, the bigger the file size it will be. Lower quality settings will enable you to burn more video to a single CD/DVD.

Maximum recording time under each setting for DVD (This is an approximate calculation, and the results may vary slightly depending on the video/audio type.)

- Best: 1 hour (SL DVD); 2 hours (DL DVD)

- Good: 1 hour & 20 minutes (SL DVD); 2 hours & 40 minutes (DL DVD)
- Normal: 1 hour & 40 minutes (SL DVD); 3 hours & 20 minutes (DL DVD)
- Average: 2 hours (SL DVD); 4 hours (DL DVD)

SL DVD = Single Layer DVD (4.7GB); DL DVD = Dual Layer DVD (8.5GB)

Note: The difference between Best and Average quality settings is nominal and will be difficult to detect on average display or analog TV screens.

Selecting Split Size:


The Split Size feature automatically splits recorded video files if they exceed the selected size. This helps to ensure that your video files will fit onto one DVD/CD. Use 4.38 GB when burning to single layer DVDs and 7.5 GB for dual layer DVDs.

Selecting Output Folder:

Specify the location on your hard drive where your recorded video files will be saved.

3.2. Split and Arrange Clips

In this section, you will split your video into smaller clips and arrange them.



Video Clip Board:

Recorded or imported video clips will be added to the Video Clip Board in icon format.

Preview Screen:

To begin editing a video clip, double-click on the clip in the Video Clip Board to move it to the Preview Screen. You can also drag the video clip over to the Preview Screen.



Play: Click to preview your work.



Previous Frame: Click to go back a single frame.



Next Frame: Click to advance the video by a single frame.



Play head: Click and drag to change the position of the video in the Preview Screen.



Split: Click to split the video at the position of the play head marker. The original video will be divided into two segments and moved back to the Video Clip Board. By repeating this procedure, you can remove unwanted segments.

Storyboard:

Select a video clip that you want to use, and drag it down to the Storyboard.

Within the Storyboard, you can click and drag a clip to move it. Dragging a clip to the left or right will change its sequence. A vertical bar will appear to show you where the clip is going to be placed on the timeline.

You can later merge all the clips in the Storyboard together to create your final video.



Next: Click to go to the next step when you are finished arranging your clips.



Back: Click to go back to a previous step. This will allow you to import or capture additional video clips at a later time.

3.3 Add Effects

In this section, you will alter your video with transitions, effects, and title screens.



Default intro title clip, ending credit clip and transition effects are added to the Storyboard automatically.

If you would like to add a new effect to one of your clips, first select the clip that you would like to apply effects to in the Storyboard. Once you have selected a clip in the Storyboard, click one of the tabs to choose how you would like to change the video. The options available are Transitions, Effects or Titles.

Transitions:

Click on the Transitions Tab and select a transition from the options available. Drag the option you selected down to the transition box located in between two video clips.

Effects:

Click on the Effects Tab and select an effect from the options available. Drag the option you selected down to the video clip you would like to add it to. Small icons will appear on the clip indicating that an effect has been applied.

Titles:

Click on the Titles Tab and select a title from the options available. Drag the option you selected down to the video clip you would like to add it to. Small icons will appear on the clip indicating that a title has been applied.

3.4. Publish

In this section, you will publish your video to a disc or output your project to a video file on your hard drive. You will need to select the type of output that you would like to create. You can choose between creating a video file and creating a disc.

3.4.1. Publish to Disc:



Menu Navigation Buttons: Click to access the chapter submenu, navigate backwards and forwards, and return to the title page of your DVD menu.

Chapters:



Create Chapter Points: Click to begin adding chapters to a clip that you have selected.



Use the transport controls  to locate positions within your clip that you want to create chapter points for.

Auto clip detection **Auto clip detection** : Select this option to automatically insert a chapter point for each clip added to the Storyboard in the Edit screen.

**Chapter points will not be added to the intro title and ending credits.*

Manual chapter insertion **Manual chapter insertion** : Select this option to add individual chapter points anywhere within a clip.

Number of chapters to insert : 3 **Number of chapters to insert** : Select this option to automatically add the selected number of chapter points evenly throughout the video

- Note: 1. You cannot insert a chapter point in the last 25 seconds of video.
2. You must have minimum 2 seconds gap between two consecutive chapter points.



Add: Click to add the selected chapter type.



Remove: Select a chapter and click this button to remove the selected chapter.



Apply: Click to apply chapters to the video.



Exit: Click to exit without saving.


Customizing DVD Menu:



Select Theme: Click to select a theme for your DVD Title Menu. This will change the way the buttons and thumbnails on your menu look.




Select Background Image: Click to select a background image for your DVD Title Menu.



Select Background Music: Click to add background music to your DVD Title Menu.



Option: Click to change DVD Menu Options



Selecting Disc type:



Using the drop-down menus shown above, you can change the type of disc you are using, and in some cases, the capacity of your disc (i.e. Single Layer/Dual Layer).

- Create Menu

Check this option if you would like to create a DVD title menu.

- Chapter Menu


Check this option if you would like to create a menu screen for selecting individual chapters.

Changing Menu Screen Format:

This changes your menu screen's aspect ratio.




Erase Disc: Click to erase all information on a re-writeable disc that is currently in your drive.






Disc Info: Click to get information about the disc currently in your drive.



Start: Click to open the Option screen and begin burning.



- Record to media

Check this option when burning to DVD or CD. Typically this is the only option you will need to have checked.

- Disc name: Enter disc name

- Drive: Select a DVD writer

- Write Speed: Select disc writing speed.

- Create DVD folder

Create DVD video folder (VIDEO_TS) and select a location on your hard drive where you would like to save the DVD video folder.


- Temp Folder

Select a temp folder where temporary files/folders will be stored.

3.4.2. Publish to Video File:



Publish – Video File: Click to select the output video format.



Output Video File Format:



Choose

your output file type. The options available are MPEG1, MPEG2, DV-AVI, AVI or WMV.

Output Video Quality:




Select a quality setting for your video. A higher quality will result in a larger file size. Certain file formats have additional quality settings which can be accessed by clicking on the gears icon to the right.

Output Folder:




This field displays the folder where your videos will be saved. You can change the output folder location by clicking on the folder icon to the right.

Output Video Properties:



This window displays details about your video. The properties that are visible in this window will be updated as you make changes to the video format, quality, codecs, etc...



Start: Click to convert your file into the new format. The video will be placed in the Output folder once the process has completed.

3.4.3 Upload to YouTube



Publish – YouTube: Click to open the YouTube Uploader screen.

Enter your YouTube account information and video information.



Upload: Click to upload to YouTube automatically.


3.4.4 Convert Video for iPod/PSP



Publish – PSP: Click to launch the PSP Converter.



Publish – iPod: Click to launch the iPod Converter.



Add Files: Click to browse your hard drive and select the file(s) that you would like to convert to PSP or iPod format.



Remove Files: Click to remove a file from the file list before beginning the conversion process.



Start: Click to convert your file into the new format. The video will be placed in the Output folder once the process has completed.


Note: Changing the encoder option, video/audio settings and output folder is optional. Using the default settings is recommended.

4. Uninstall honestech Easy Video Editor 3.0

4.1. Find program group

You can uninstall VIDEO EDITOR 8.0 from its program group. Go to the Start Menu and find the VIDEO EDITOR 8.0 program group, and then follow the steps below.


START → PROGRAMS → *honestech* VIDEO EDITOR 8.0 → Uninstall *honestech* VIDEO EDITOR 8.0



4.2. Select to uninstall


When you click **UNINSTALL**, you will see a pop-up screen for confirmation.

Please click **[Yes]** to uninstall.




4.3. Start Uninstall Process

The uninstall process will begin. Please wait for the process to complete.



4.4. Uninstall Completed

When the confirmation message is displayed, click **[OK]** to finish the process.



***honestech* Products**



honestech

Claymation Studio 2.0

With honestech Claymation Studio, you can easily create stop motion video. Capture images using a digital camera, webcam or DV camcorder and add background images, audio, and music to create your own stop-motion movies.

Features

- Adjustable Capture Resolution (320x240~720x576)
- Chroma Key Effect
- Partial Chroma Key Effect
- Rotoscope
- Onionskin
- Audio dubbing
- DV camcorder compatibility
- Auto Capture
- Grid/Key drawing
- Copy, Cut & Paste
- Intro & Ending Title
- Import Images
- Audio Recording
- Background Music
- Text on Screen
- Chroma key on imported images
- Supports WMV, AVI & MPEG format

System Requirements

- Operating System:
Windows XP
Windows Vista
- Processor:
Pentium IV 1.8GHz or equivalent
- Memory:
128MB of RAM
(256MB or higher recommended)
- Free Hard Disk Space:
50MB for program installation
- Other:
Microsoft DirectX 9.0(or higher)
Windows Media Format SDK 9 (or higher)
Windows Media Player 7 (or higher)



Optional Devices

- Video Capture Device:
Web Camera , DV-Camcorder
- Audio Capture Device:
microphone

Input/Output Formats

- Image input:
JPEG, BMP, PNG, GIF
- Audio input:
MP3, WAV
- Video Output:
AVI, WMV and MPEG

honestech

Audio Recorder 2.0 Deluxe

*With just a few clicks,
convert your analog music into digital formats
including MP3s and audio CDs.*

Convert all of your analog music, including LP, 8-track, and cassette tapes into WAV file, MP3, audio CDs and MP3 CDs, and listen to them on your portable music players.



Features

1. Noise Reduction

Improve audio quality by reducing unwanted noise or statics.

2. Built-in Normalizer

Controls irregular volume by increasing or decreasing as needed

3. Digital Amplifier

Increase audio volume for the music players with low audio output.

4. Auto Track Split

Easily split your audio clip into multiple tracks automatically by detecting the muted sections.

5. Audio Editing

Remove unwanted audio segments or split audio clips.

6. Supported Output

Turn your analog music into WAV, MP3, MP3 CDs and audio CDs.

System Requirements

- Operating System:
Windows XP Service Pack 2
Windows Vista
- USB 2.0 Host Controller/Port
- Processor:
Intel® Pentium® 3 800 MHz or higher
- Memory:
256MB of RAM
- Free Hard Disk Space:
70MB for program installation and 4GB for Audio Editing
- Other:
DirectX 9.0 or higher CD Writer for Audio CD, MP3 CD

*** USB 2.0 Audio Conversion Device Included.**

honestech

Fireman CD/DVD Burner 3.0

honestech Fireman CD/DVD Burner 3.0 allows you to create data, audio, or video discs. You can also import audio from music CDs and create system backup/recovery discs and bootableCD/DVD.

With DVD Authoring Studio, you can create your own stylish video DVD with ease. Create photo slideshow DVD of using your digital photos that you can also play on your home DVD player.

Using LightScribe discs, you can create custom laser-etched CD/DVD labels with your own photos, artwork, and text.

You can make and burn ISO images which provide a way to store all files on a disc as a single file. Erase CD/DVD RW discs and create CD/DVD labels and covers.

Features

1. Data Burning

- Data CD
- Data DVD
- Audio and data CD
- Bootable CD
- Bootable DVD

2. Audio Burning

- Audio CD
- MP3 CD/DVD
- WMA CD/DVD
- Audio and data CD
- Import audio from music CD

3. Video Burning

- DVD
- Video CD
- Super Video CD
- DVD-video files

4. Backup

- Create backup files
- Restore from backup files

5. Utilities

- Erase CD/DVD
- View disc information
- Create disc Label/Cover
- Supports LightScribe



- Can view/slideshow photo
- Create/burn ISO image

BONUS SOFTWARE

- *honestech* DVD Authoring Studio 2.0

System Requirements

- Operating System:
Windows XP
Windows Vista
(<http://www.honestech.com/vista>)
- Processor:
Pentium III 800 MHz or equivalent
- Memory: 256MB of RAM
- HDD:
Minimum 10GB of free space
- Writer:
DVD-ROM, DVD-R/RW, DVD-RAM,
DVD+R/RW, DVD-Dual, DVD-Multi,
or DVD-ROM/CD-RW drive with 1394,
USB2.0, ATAPI, or SCSI interface
- LightScribe:
requires optical drive with
LightScribe feature
- Audio device:
PCI sound card, USB audio box,
or integrated sound card
- AGP or PCI graphics card that
supports DirectDraw overlay.
- Resolution:
minimum of 1024 x 768 or
1280 x 1024 recommended.

honestech **DVD Authoring Studio 2.0**

With *honestech* DVD Authoring Studio 2.0, you can archive up to 27 hours movie in one dual-layer DVD. Create your own high-quality DVD movies with this powerful software. Simply capture video from your web cam, digital camera or TV using your TV tuner/capture device and convert the video into DVD.

Features

1. Ultra-Long DVD format

Archive 16 hours of video on a DVD or 27 hours of video on dual-layer DVD.

2. Capture

Capture videos in various formats from TV capture card and USB camera or DV Camcorder.

3. Import from DVD

Import videos from existing DVD movies.

4. Edit

Edit videos or photo shows, transitions, effects, texts, audios and trims.

5. Menu

Provides various DVD menu themes, and supports motion menu.

6. Various outputs


Support Ultra-Long DVD, DVD, VCD, SVCD, MPEG files, VIDEO_TS folder and disc image file.

7. Dual-Layer Support

Support dual-layer DVD burning.

8. Copy Disc

Make back up copies of your CD/DVD.



Operation System

Windows XP SP2

Windows Vista

(<http://www.honestech.com/vista>)

System Requirements

DirectX 9.0 or higher

Pentium IV 1 GHz or higher

256MB RAM or more

honestech

Burn DVD 3.2

honestech Burn DVD 3.2 lets you convert your video of various formats into DVD, VCD and SVCD. The simple 3 step interface guides user through the entire process. *honestech* Burn DVD 3.2 is easy enough for novice yet powerful enough for experienced users.

Features

1. Automatic MPEG Conversion Feature

Automatically detects and convert the original video file into DVD, Video CD or SVCD format.

2. Audio Format Selection

Audio formats can be converted to LPCM in order to be played at PS2.

3. Menu Creation

Create customized DVD or Video CD menus with ease using the templates.

4. Test Recording Feature

Test your DVD/CD writer before actually burning DVD/CD.

5. Data CD


Supports data burning on CD media.

6. UDF (Universal Disk Format, DVD Image File) Creation

You can make and burn UDF image file which provides a way to store all files on a disc as a single file.

7. XVCD and XSVCD Format Support

Create high-quality video CDs using XVCD and XSVCD formats.



Operation System

Windows XP SP2

Windows Vista

(<http://www.honestech.com/vista>)

System Requirements

DirectX 9.0 or higher

Pentium IV 1 GHz or higher

256MB RAM or more

honestech

Photo DVD 3.0

honestech Photo DVD 3.0 is a simple program that allows you to create personalized photo slide shows on CD/DVD to watch on your television or computer. You can even add background music or a narrated audio file to your slide show.

Features

1. Create photo slide shows to various video formats including DVD, VCD, SVCD, mini-DVD, MPEG, AVI, DV-AVI, and WMV.
2. **Edit Pictures**
honestech Photo DVD 3.0 allows you to edit your pictures and add text or special effects.
3. **Add Background Music**
You can add audio files to your photo slide show.
4. **Add Transition Effects**
You can add transition effects between your pictures.
5. **Preview**
Preview your photo slide show before burning it to CD/DVD.



Operation System

Windows XP SP2
Windows Vista
(<http://www.honestech.com/vista>)


System Requirements

DirectX 9.0 or higher
Pentium IV 1GHz or higher
256MB RAM or more
15GB HDD or more
CD or DVD writer

honestech

Video Patrol 5.0

honestech Video Patrol 5.0 provides a comprehensive personal video monitoring surveillance solution. You can monitor your home or office from anywhere with broadband internet access. You can control up to three cameras at a time, send e-mail notices to specified email accounts, and schedule monitoring time slots. You can record surveillance videos in MPEG format when a motion is detected.



Features

1. Basic Surveillance

Record video (in mpeg format) continuously or only when a motion is detected. You can also specify motion from certain area within viewing area of PC camera to trigger the surveillance system.

2. Email Notification

Send email notices to specified e-mail addresses

3. Scheduled Monitoring

Specify desired monitoring time slots for surveillance system to be active. (e.g....: one, daily, or weekly)

4. Multiple PC Cameras

Supports up to three PC cameras, and you select individual detection mode and response action for each PC camera. In order to avoid conflict in device recognition by your PC, we recommend that you use different brand or model for multiple PC camera operation.

5. Data Backup/Burning

You can create backup video files on CD or DVD

6. File List Management

Easily manage the recorded video files with browsing and selection feature for watching or burning.

7. FTP Server Option

Back up your videos by uploading them to your FTP server or burn DVD (if available)

8. Free Online membership (www.my-iptv.com)

View surveillance video from PDA, Sony PSP and PDA mobile phone

System Requirements

- Capture Device:
USB Camera
- Operating System:
Windows XP
Windows Vista
(<http://www.honestech.com/vista>)
- Processor:
Pentium IV 2.0 GHz or equivalent
- Memory:
256MB of RAM
- Other:
DirectX 8.1 or higher
Windows Media Player 6.4
(or higher)
CD Writer for Data-CD
DVD Writer for Data-DVD
- Video Output:
MPEG-1, MPEG-1 VBR



Honestech, Inc.

North and Latin America

P.O. Box 26365 Austin, TX 78755

Toll Free Number : 1-877-484-6246 (U.S. Only)

Fax : 512-248-2215

eMail : support@honestech.com

For local and international support phone number,
please visit our website: www.honestech.com/support

Honest Technology Europe

United Kingdom: support.uk@honestech.com

France: support@honestech-fr.com

Germany: support@honestech.com

Spain: support@honestech-es.com

Honest Technology Taiwan

Address : Room 6E08, No. 5, Sec. 5, Hsin-Yi Road., Taipei, Taiwan, R.O.C
< Taipei World Trade Center >

Tel : +886 2 8780 8023

Fax : +886 2 8780 4582

eMail : Taiwan@honestech.com

Honest Technology Japan

Address : MS Bldg 6F, 2-25-4, Taitou, Taitou-Ku, Tokyo, 110-0016 JAPAN

eMail : japan@honestech.com

Honest Technology Korea

Address : Kyung-Dong Bldg, 5F, 906-5 Jijok-Dong, Yuseong-Gu, Daejeon, Korea 305-330

Tel : +82-42-477-0717~8

Fax : +82-42-477-0719

eMail : support@honestech.co.kr